



1. AFTER NOTCHING THE PIPE LOGS RUN A BEAD OF EPOXY ALONG THE TOP OF THE LOG TO BOND WITH THE NEXT LOG
2. BEFORE CUTTING HOLES IN LOG WALLS FOR DOOR AND WINDOWS COAT THE INSIDE OF THE WALL WITH AN EPOXY PUTTY.